

HOLZ RENOVATOR

THE EFFECTIVE SOLUTION FOR QUICK WOOD RENOVATION

PURPOSES

Holz Renovator is used for quick renovation of wood; it cleans of dirt and darkness; it restores the natural colour of the timber. It is designed for cleaning and renovation of facades, wooden houses, terraces, deck etc. It is possible to treat such types of timber as teak and mahogany. The product is suitable for both **internal** and **external** application.

MAIN ADVANTAGES

- Holz Renovator is chlorine- and chlorine compounds **free** and therefore does not destroy the wood.
- It is possible to re-apply the product.
- It restores the natural colour of timber.
- After the treatment the strength and durability of wood increase.
- Holz Renovator does not contain biocides.
- The solution is water based.
- Fire- and explosion safe material.

DIRECTIONS FOR USE

Holz Renovator is applied on surfaces cleaned of dirt, dust and other coverings with brush, roller or spray at the temperature not lower than +5°C, providing the normalized total consumption not lower than 100-150 ml/m². Let it work for 10-20 minutes. Scrub treated surface with brush whilst rinsing with water or use a pressure washer (max 80 bar). In case of heavily soiled surface procedure could be repeated.

The dried processed surface can be covered with oil (for example, Holz Oil and others) and other protective and decorative materials.

NB! Do not mix it with other solutions! Stir thoroughly before applying! (Bottom sediment doesn't affect the quality of the product). If the liquid gets to the coloured surface, wash immediately with plenty of water!

STORAGE AND TRANSPORTATION

Store and transport HP Renovator in hermetically sealed original containers separately from food products. Keep at temperature above -5°C. The storing period of the product is 24 months.

COMPOSITION

Iron orthophosphate dihydrate, water and additives.

SAFETY MEASURES

Keep locked up and out of the reach of children. Do not get in eyes, on skin, or on clothing. Rinse thoroughly in case of contact with eyes or mouth. Get medical advice/attention if you feel unwell. Use only outdoors or in a well-ventilated area. Holz Renovator is a fire-safe and explosion-proof material. Discard with other household waste products.